The United States of America

The Director of the United States Patent and Trademark Office

Has received an application for a patent for a new and useful invention. The title and description of the invention are enclosed. The requirements of law have been complied with, and it has been determined that a patent on the invention shall be granted under the law.

Therefore, this

United States Patent

Grants to the person(s) having title to this patent the right to exclude others from making, using, offering for sale, or selling the invention throughout the United States of America or importing the invention into the United States of America for the term set forth below, subject to the payment of maintenance fees as provided by law.

If this application was filed prior to June 8, 1995, the term of this patent is the longer of seventeen years from the date of grant of this patent or twenty years from the earliest effective U.S. filing date of the application, subject to any statutory extension.

If this application was filed on or after June 8, 1995, the term of this patent is twenty years from the U.S. filing date, subject to any statutory extension. If the application contains a specific reference to an earlier filed application or applications under 35 U.S.C. 120, 121 or 365(c), the term of the patent is twenty years from the date on which the earliest application was filed, subject to any statutory extensions.

Jon W. Dudas

Director of the United States Patent and Trademark Office

NOTICE

If the application for this patent was filed on or after December 12, 1980, maintenance fees are due three years and six months, seven years and six months, and eleven years and six months after the date of this grant, or within a grace period of six months thereafter upon payment of a surcharge as provided by law. The amount, number of timing of the maintenance fees required may be changed by law or regulation. Unless payment of the applicable maintenance fee is received in the United States Patent and Trademark Office on or before the date the fee is due or within a grace period of six months thereafter, the patent will expire as of the end of such grace period.



S007455412B2

(12) United States Patent

Rottcher

(10) Patent No.:

US 7,455,412 B2

(45) Date of Patent:

Nov. 25, 2008

(54)	MIRROR HAVING A PORTION IN THE FORM						
	OF AN INFORMATION PROVIDER						

(75) Inventor: Oliver Rottcher, Gottmadingen (DE)

(73) Assignee: Mirror Image AG, Steinach (CH)

(*) Notice: Subject to any disclaimer, the term of this patent is extended or adjusted under 35

U.S.C. 154(b) by 0 days.

(21) Appl. No.: 09/883,729

(22) Filed: Jun. 18, 2001

(65) Prior Publication Data

US 2002/0015226 A1 Feb. 7, 2002

(30) Foreign Application Priority Data

(51) Int. Cl.

G03H 1/00 (2006.01) G03B 21/56 (2006.01) G02B 5/08 (2006.01)

(56) References Cited

U.S. PATENT DOCUMENTS

1,680,016	Α	*	8/1928	Dawley	434/395
1,849,708	Α	*	3/1932	Colbert et al	434/408
2,221,888	Α	*	11/1940	White	40/219

2,221,889	A	*	11/1940	White 40/219
,202,607	A		5/1980	Washizuka et al.
,517,040	Α		5/1985	Whitted
,588,267	A	*	5/1986	Pastore 359/636
1,630,904	A	*	12/1986	Pastore 359/636
,747,223	A	*	5/1988	Borda 40/219
,765,076	A	*	8/1988	Sada 40/219
0299,491	S		1/1989	Masuda
0300,642	S	*	4/1989	Pawlik et al D20/10
,123,192	Α	*	6/1992	Hsieh 40/442
,148,283	A		9/1992	Taddeo

(Continued)

FOREIGN PATENT DOCUMENTS

29916732 U1 * 3/2000

DE

(Continued)

OTHER PUBLICATIONS

"Lake Las Vegas homeowners show creativity." located at http://lasvegasnewspapers.com/realestate/REMay-21-Sun-2000/Front/13554146.html: retrieved on Dec. 17, 2004 (2 pages).

(Continued)


Primary Examiner—Diane I. Lee Assistant Examiner—Magda Cruz

(74) Attorney, Agent, or Firm—Morrison & Foerster LLP

57) ABSTRACT


In a mirror with a non-reflective portion provided within its reflective mirror surface as an information provider the portion is transparent and is backed by a display. The display has a moving image or has a colored image representation. Preferably at least one loudspeaker is connected to the display behind the mirror surface. That loudspeaker can also be connected to an input device.


11 Claims, 3 Drawing Sheets




US 7,455,412 B2 Page 2

U.S. PATENT	DOCUMENTS		6,650,470 B1 * 11/2003	Turner et al.	
5,210,967 A * 5/1993	Brown 40/219		FOREIGN PATE	ENT DOCUM	MENTS
5,228,879 A * 7/1993	Fromm 446/219				
5,416,313 A * 5/1995	Larson et al 250/214 AL	DE	299 16 732 U1		
5,631,638 A * 5/1997	Kaspar et al 340/902	EP	0 552 768	7/1993	
5,642,238 A 6/1997	Sala	EP	0 937 601	8/1999	
5,887,369 A * 3/1999	Danielczak 40/428	FR	2 586 182	2/1987	
5,956,181 A 9/1999	Lin	FR	2 738 931	3/1997	
, ,	Takeuchi et al.	GB	2 274 733	8/1994	
-, -,	Buckley et al 359/839	JP	08-173285	7/1996	
6,152,551 A 11/2000	3	JP	08-308700	11/1996	
-, ,	DeLine et al 340/815.4	WO	WO-95/23401	8/1995	
6,200,010 B1 * 3/2001	Anders 362/511		OTHER DI	BLICATION	TC.
6,320,591 B1 * 11/2001	Griencewic 345/582		OTHER PU	BLICATION	(9
6,477,464 B2 * 11/2002	McCarthy et al 701/213	Germa	on Office Action dated Au	ig 28, 2007 di	rected to counternart
6,543,163 B1 * 4/2003	Ginsberg 40/219	German Office Action dated Aug. 28, 2007 directed to counterpart German Application No. 01 115 047.1-2214/1168285.			
	Meine 359/630	Community production 110. 01 115 047.1 2214/1100205.			
	Lang et al 340/435	* cite	d by examiner		







BACKGROUND OF THE INVENTION

The present invention concerns a mirror with a non-reflective portion provided within its reflective surface, as an information provider

DE 299 16 732 U1 depicts as state of the art an advertising mirror with a mirror layer which is semi-transparent at least in 10 both alone and also—preferably—in conjunction with the a portion thereof. In that advertising mirror in accordance with the invention at least in the portion serving as the advertising or information surface, the mirror layer is followed in the direction from the outside of the mirror towards the rear side thereof by an anti-reflection layer, an advertising layer 15 does a person have to be physically present in order to input comprising a transparent flat material, and a lighting member of a flat configuration. That arrangement suffers basically from the following problems: the communication of information is limited to a stationary image or still image which is back-lit in the form of a motif carrier to be introduced—for 20 recorder, DVD-player, CD-player or the like. In order to example a transparency—and in that way is rendered visible to the person viewing same; exchanging the individual motif carriers is complicated and difficult as, to introduce fresh motif carriers or items of information to be communicated. be manually replaced by a new one.

With knowledge of that state of the art, the object of the present invention is to eliminate the recognized deficiencies and to provide a mirror which differs in regard to previously known advertising mirrors in the nature of and possible varia- 30 tions in the items of graphic information to be communicated, and which permits ease of handling when introducing and changing the items of information or the motif carriers.

SUMMARY OF THE INVENTION

The foregoing object is attained by providing a mirror with a non-reflective portion provided within its reflective surface as an information provider, wherein at least a portion of the backed by a display.

In accordance with the invention the portion of the mirror surface, which is in the form of the information provider, is as clear as glass, that is to say completely transparent for seeing for optically effectively presenting objects. In particular that display should be capable of presenting a moving image. Two or more portions of that kind may also be provided in the mirror surface.

The semi-transparent mirror layer known from the state of 50 the art is therefore the subject of development in that a moving image—preferably a colored image—is now produced within the actual mirror surface in that portion.

In accordance with the invention, a moving colored image is used for communicating information by virtue of that color 55 mirror after removal of a rear wall, display. In order to keep the thickness of the mirror as small as possible, in accordance with the invention a flat image display or flat screen is to be used. It has also proven to be advantageous to use a display of thin film transistor (TFT) or plasma technology type, but also it is possible to use other technolo- 60 gies for motif representation purposes, such as for example holograms for three-dimensional image representation. In particular it is also possible to use a display involving touch screen technology which makes it possible to call up various representation of different kinds of images such as for example television pictures, computer images and animation,

an Internet surface and a multi-media surface, in the display or information surface provided for that purpose.

The inventor also proposes the communication of audio elements; the incorporation of at least one loudspeakerpreferably connected to the display or another peripheral device for operation of the display such as for example a PC, video recorder or DVD-player—makes it possible to communicate audio elements such as for example music, a speech backing or the like. The audio elements can be reproduced image information.

The form of feeding in information is to be considerably facilitated for the purposes of greater ease of handling, and it is to be ensured that the mirror does not have to be opened nor data or fresh motifs into the information mirror. For that purpose, the installed display and the loudspeakers are supplied with the items of information to be represented from a suitable peripheral device—once again a computer, video change the items of information to be communicated, it is just the inserted reproduction medium that is changed, that is to say for example the video cassette of the video recorder.

In general, a computer is used for operation of the display the mirror has to be open and the existing motif carrier has to 25 and the loudspeakers, in which case the items of information and data to be represented can be transferred onto that computer from another computer by data transfer—for example integrated services digital network (ISDN) data transmission or other transmission options.

> The foregoing features mean that opening of the mirror is now no longer necessary when changing the information or the motif, so that it becomes possible for the mirror to be fixedly installed at suitable locations. The change in motif can also be effected in the absence of an operator.

35 In accordance with the invention, break-proof glass can preferably be used for the mirror, and volume control for the loudspeaker or loudspeakers can also be effected by means of remote control—for example infra-red control. In addition it has proven to be desirable to install a radio receiver module mirror surface is transparent for seeing therethrough and is 40 for the graphic data or to mount the described loudspeakers outside the mirror and connect them to the display or input

That therefore affords a communication mirror of variable size of a very flat frame structure, in which changing or therethrough, and is backed with a display, an image viewer 45 replacing the items of information is readily possible by virtue of a change in data carrier in the input device.

BRIEF DESCRIPTION OF THE DRAWINGS

Further advantages, features and details of the invention will be apparent from the description hereinafter of preferred embodiments and with reference to the drawing in which:

FIG. 1 shows a perspective view of a framed mirror,

FIG. 2 shows a perspective view of the rear side of the

FIGS. 3 and 4 show views corresponding to FIG. 1 and FIG. 2 respectively in relation to a frame-less configuration of the mirror, and

FIG. 5 shows a perspective view of the front of a mirror with additional devices.

DETAILED DESCRIPTION

A wall mirror 10 of a length a for example of about 140 cm functions and program procedures on the display and also the 65 and a height h of 80 cm has a frame 12 of metal or plastic material—possibly also of wood—of a width b of between about 3 and 5 cm.

The frame 12 is composed to two channel-shaped longitudinal profile members 14 and two shorter transverse profile members 14_a of identical cross-section—forming mitered corners 18; the rearward limb portions 15 of the frame profile members 14, 14_a define a mounting plane for a rear wall (not 5 shown in the drawing), while the front limbs 16 of the frame members form a frame-shaped abutment for a mirror insert 20 which is held within same in the frame 12.

Provided in the mirror surface 22 of the mirror insert 20 at spacings e, e₁ in relation to the adjacent limbs 16 of the profile 10 provider, and a frame having a flat frame structure, members is an area 26 through which it is possible to see having been left free for example upon chemical deposition of a backing or silver layer 24—, the length a₁ of the area 26 being in this case about 30 cm and its height h, being about 24 cm, while associated therewith at the rear thereof is an elec- 15 tronic color display 28; the latter is screwed to transverse struts 19 of the frame 12 which in turn are fixed at their ends to the rearward limb portions 15 of the profile members. Provided beside the color display 28 in FIG. 2 is a cooling device 30—for example a cooling fan—which is also 20 mounted to the transverse struts 19.

Indicated at 32 above the display 28 is a control board which permits actuation of the display 28 with an external input device 50 which is shown in FIG. 5, such as a computer, video, DVD, CD or the like. Projecting from the control board 32 are a cable connecting plug 34 for a cable 48—for example a cinch connecting cable—of the input device 50 and a mains network connecting plug 36 for the power supply for the color display 28 and the cooling device 30 by way of the connecting cable 37 of a power source 54.

The control board 32 is mounted to the transverse profile member 14, which is adjacent thereto, and disposed opposite it on the other transverse profile member 14_a of the frame 12 in the interior 40 of the mirror is a loudspeaker 38 which fits closely against a region 42 of the frame 12—which region 42 is perforated or provided with a slot or aperture insert—and the loudspeaker is provided with connection elements 44 for external devices. The interior 40 of the mirror is closed to prevent unauthorized access by a rear wall (which as mentioned is not shown in the drawing) comprising a metal, wood 40 receiver module for the moving image. or plastic plate or panel, and it can be opened by actuating a cylinder lock 46 of the frame 12.

In the embodiment of the mirror 10_a in FIGS. 3 and 4 the area of the mirror insert 20 is larger than the frame 12 in front means. of which the mirror insert 20 is fitted; the latter projects beyond the edges of the frame 12 on all sides by a distance i.

In this embodiment the mirror surface 22 is part of a mirror attachment 21 and the same is fitted onto a frame 12 to form a mirror interior 40.

In accordance with the invention the multi-media mirror can also be integrated into items of furniture, bars and counters, mirror-bearing cupboards or cabinets or the like. The invention claimed is:

1. A wall mirror with a non-reflective portion provided within a reflective surface of the mirror as an information

wherein at least a portion of the mirror surface is clear as glass or totally transparent and is backed by a flat screen or a color display, the flat screen or the display being provided with a moving image, the flat screen or the display being attached to the frame, and wherein

the mirror surface is part of a mirror insert which is associated with the frame to form a closed mirror interior, or the mirror surface is part of a mirror attachment which is fitted onto the frame to form a closed mirror interior.

2. The mirror according to claim 1 wherein the flat screen or the display employs TFT or plasma or hologram technolo-

3. The mirror according to claim 1 wherein behind the 25 mirror surface at least one loudspeaker is connected to the flat screen or the display.

4. The mirror according to claim 3 wherein the loudspeaker is associated with a perforated region of the frame.

5. The mirror according to claim 1 wherein behind the 30 mirror surface at least one loudspeaker is connected to an input device.

6. The mirror according to claim 1 wherein the flat screen or the display is connected to an input device.

7. The mirror according to claim 6 wherein the input device is optionally an external input device.

8. The mirror according to claim 1 wherein the flat screen or the display is secured to strut means which are associated with the frame.

9. The mirror according to claim 1 further with a radio

10. The mirror according to claim 1 further with an integrated remote operating means for volume control.

11. The mirror according to claim 10 wherein the integrated remote operating means is an infrared operating